

MODELS: 8150-RS
8150-RS1
8150-RS1-220

BUTTER SPREADERS

INSTRUCTIONS

MANUAL MODEL

1. REMOVE BUTTER CHAMBER COVER
2. FILL WITH BUTTER
3. REPLACE COVER
4. PLACE SPREADER ON GRILL TO MELT BUTTER
5. ROLL BREAD OVER ROLLER TO APPLY BUTTER

ELECTRICAL MODELS

1. PLUG INTO OUTLET WITH CORRECT VOLTAGE FOR THE MODEL
2. REMOVE BUTTER CHAMBER COVER
3. FILL WITH BUTTER
4. REPLACE COVER
5. WHEN BUTTER IS MELTED ROLL BREAD OVER ROLLER TO APPLY BUTTER

SERVICE PARTS

<u>DESCRIPTION</u>	<u>PART NO.</u>
BUTTER COVER	80153
ROLLER	80074
CORD WITH ELEMENT 24W 120	47232
CORD WITH ELEMENT 24w 220V	47235