

NEMCO FOOD EQUIPMENT

301 MEUSE ARGONNE, HICKSVILLE, OHIO 43526 PHONE (419) 542-7751

OPERATING INSTRUCTIONS FOR HEAT SHELF MODELS:

6300-24A & 6300-24A220

TO OPERATE:

- *REMOVE UNIT FROM BOX, REPORT ANY DAMAGES IMMEDIATELY.
- *PLACE UNIT ON A SOLID FLAT HORIZONTAL SURFACE.
- *LEVEL THE UNIT BY USING THE ADJUSTABLE FEET.
- *REMOVE PROTECTIVE PLASTIC SHEET FROM TOP SURFACE.
- *PLUG UNIT INTO A GROUNDED OUTLET.
- *TURN UNIT ON.

NOTES:

THIS HEAT SHELF IS DESIGNED TO HOLD FOODS AT SERVING TEMPERATURES. TO MAINTAIN TEMPERATURES, KEEP FOODS COVERED WHEN NOT BEING SERVED.

*DO **NOT** PLACE FOOD ONTO THE ALUMINUM TOP. FOOD MUST ALWAYS BE PLACED IN A CONTAINER.

WHEN A NEW UNIT IS OPERATED FOR THE FIRST TIME, A SLIGHT ODOR AND SMOKE MAY BE NOTICED. THIS IS NORMAL AND TO BE EXPECTED UNTIL THE PROTECTIVE FILM COATING ON THE HEATING ELEMENT BURNS OFF, USUALLY 20-30 MINUTES.

TO CLEAN:

- TURN OFF AND UNPLUG UNIT.
- WIPE DOWN USING NYLON PAD WITH A MILD SOAP AND WATER SOLUTION.

NOTE:

BLEACH IS NOT RECOMMENDED, IT MAY DISCOLOR THE ALUMINUM TOP. WHEN NOT IN USE, UNPLUG UNIT.

MODEL 6300-24A

120 Volts
300 Watts
2.5 Amps

MODEL 6300-24A220

220 Volts
300 Watts
1.36 Amps

DO NOT IMMERSE!